



Distance Needed from the Wall for Full Recline: **2"**

Minimum Doorframe  
Width: **28"**



**\*Rotate Chair 90°** to fit  
through the door before  
attaching backrest



Distance Needed from the Wall for Full Recline: **2"**

Minimum Doorframe  
Width: **28"**



**\*Rotate Chair 90°** to fit  
through the door before  
attaching backrest