



Distance Needed from the Wall for Full Recline: **4"**

Minimum Doorframe
Width: **28"**



***Rotate Chair 90°** to fit
through the door before
attaching backrest