



Distance Needed from the Wall for Full Recline: **7.5"**

Minimum Doorframe
 Width: **28"**



***Rotate Chair 90°** to fit
 through the door before
 attaching backrest