

attaching backrest







Distance needed from wall for full recline: 6.5"