





Distance needed from wall for full recline: 5.5"





*Rotate Chair 90° to fit through the door before attaching backrest