



*Rotate Chair 90° to fit through the door before attaching backrest

Distance needed from wall for full recline: **6"**



Arm Width
6.75"



Surface Width
72"



Minimum Doorframe
Width
28"

Seat Height
44"



Full Recline
66"



*Rotate Chair 90° to fit through the door before attaching backrest